


### LOCK/UNLOCK FEATURE:

1. Press the up and down arrow simultaneously, this will lock and unlock the device.
2. The lock icon will appear closed when the device is locked.
3. The lock icon will appear closed when the device is unlocked.




### SLEEP MODE ACTIVATION:

1. Press the left and right arrow simultaneously, to activate and to deactivate.
2. When sleep mode is activated, an S will appear in the bottom right side of the footer.
3. When sleep mode is deactivated, a S will not appear in the bottom right side of the footer.



### RUN TIME LOCK OUT:

1. Press the left and down arrow simultaneously, to activate and to deactivate.
2. When run time lock out is activated, the run time font will be in blue.
3. When run time lock out is deactivated, the run time font will be black.



### ACCESSING THE FACTORY ADMINISTRATION:

1. Press menu button, arrow down to setting icon, once setting icon is highlighted, press the menu/select button, scroll down to factory admin, press the menu/select button, and then enter the passcode and press the menu/select button.

The password for the factory admin: *the up arrow, the down arrow, the left arrow, the right arrow, the up arrow, the down arrow, and then press the menu/select button.*

